## PAINT BRUSH RESTORER

To remove general household paints and varnishes that have dried and hardened on decorating brushes

Directions: Soak brushes in the product by suspending the brush including part of the ferrule but not the handle in a glass or metal container (not plastic). Allow to soak for at least 4 hours but preferably overnight in a location away from where vapours could be inhaled; cover with cling film if necessary to reduce evaporation. Agitate the brush against the bottom / side of the container to loosen paint fragments. Remove from the container and dry in a cloth / paper flexing the bristles, this will help to loosen more paint as flakes; the product does not redissolve the paint. Re-immerse as necessary or use a fine wire brush to comb the bristles to remove remaining adhered paint. Finally wash the brush in water and allow to drain.

Use in a well ventilated area and protect surrounding areas from accidental splashes.

## **HEALTH, SAFETY & ENVIRONMENTAL INFORMATION**

· Repeated exposure may cause skin dryness or cracking.

 Flammable liquid and vapour. 

 May be fatal if swallowed and enters airways.
 Causes skin irritation.
 Causes serious eye irritation.
 May cause drowsiness or dizziness.
 Keep out of reach of children.
 Keep out of the children.
 Keep out of the children.
 Nor induce vomiting.
 Flow SKIN (or hair): Take off immediately all contaminated lothing. Rinse skin with water.
 IF NEYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
 Dispose of contents/ container to local/national regulations.

> Very High VOC content >50% VOCs (Volatile Organic Compounds) Contribute to atmospheric pollution.

## **Barrettine**

St. Ivel Way, Warmley, Bristol BS30 8TY. **T:** 0117 960 0060 **F:** 0117 935 2437 **E:** sales@barrettine.co.uk **www.barrettinePro.co.uk**  UFI: 4P00-X05U-200J-PECP



DANGER